

Stitch Patterning Checklist



1 Knit in Pattern

Swatches/rectangles with all-over stitch patterns

☐

Connect computer, SilverLink, Curl Cord and Machine

☐

INTERACTIVE KN ITTING: Set swatch size

☐

Set the point cams to the edges of the knitting

☐

Set the Cam Lever to the stitch type (fairisle, tuck, slip, etc)

☐

Follow the Interactive Knitting Prompts

Stitch Patterning Checklist



2 Knit in Pattern

Isolated motifs or custom pattern placement

☐

STITCH DESIGNER: create a new stitch pattern

☐

Import motifs or draw a stitch pattern

☐

Connect computer, SilverLink, Curl Cord and Machine

☐

Interactive Knitting: set up swatch size

☐

Set the point cams to the edges of the knitting

☐

Set the Cam Lever to the stitch type (fairisle, tuck, slip, etc)

☐

Follow the Interactive Knitting Prompts

Stitch Patterning Checklist



3 Knit a Garment Piece in Pattern

All-over stitch patterns and isolated motifs

☐

STITCH DESIGNER: New stitch pattern from GARMENT PIECE

☐

Import motifs or draw a stitch pattern

☐

Connect computer, SilverLink, Curl Cord and Machine

☐

Interactive Knitting: set up SHAPE file

- Select SHAPE FILE from UPPER list
- Select a Piece
- Choose "Integrated with Stitch Pattern"

☐

Set the point cams to the edges of the knitting

☐

Set the Cam Lever to the stitch type (fairisle, tuck, slip, etc)

☐

Follow the Interactive Knitting Prompts